





PCT/US97/06818

















FIGURE 6




FIGURE 7





FIGURE 8

PCT/US97/06818

IPFX
(Inverted Para - Flow Cross Pipe)




No. 1 - 7 illustrate the flow of refrigerant starting at the compressor discharge.

FIGURE 9



BTU/hr CAPACITY

1 H.P. Compressor




0/

<u>oegezze nango</u>

BTU/hr CAPACITY

1/4 H.P. Compressor



Evaporator Temperature

HEUKE II